


Wearing the AH8 Transmitter


The AH8 can be re-sized to fit comfortably on your head. The correct way to wear your AH8 Headset transmitter is over the ears, as you would wear a pair of eyeglasses. Because the AH8 Headset is specially designed to be used up close, be sure to position the microphone near the corner of your lips. To avoid feedback problems, take care not to cover the mic capsule with your hand.

Position the AH8 over your head so that the body of the transmitter is behind your head. Adjust the headset so that it fits comfortably on your ears and is secure against your head.

Note: If wearing glasses, it is recommended to put the AH8 transmitter on first than place glasses over the transmitter.




AH8 Transmitter Headband Adjustment Instructions



If the AH8 headset is too large, push the sides of the headband in to decrease the width. If the transmitter is too small, pull the sides of the headband out to increase the width.

WARNING:

The ear hooks are NOT adjustable. DO NOT bend the earhooks as this will damage to the headset.



Position the microphone towards the corner of your mouth, approximately 1/2" away from the lips.

To help reduce p-popping, install one of the (4) included windscreens.

Cleaning the AH8 transmitter:

The headset, microphone and gooseneck should be cleaned after each use. Use clean, fresh water on a towel or clean rag, gently wiping away any contaminations that may have accumulated during use.

The windscreens should be washed with clean water after each use.